

EASYCAL® G2 Automatic Calibration Station



Lifeloc

Professional Breath Alcohol Tester

Breath alcohol testing compliance just got easier, faster, and more affordable. The EASYCAL G2 calibration station automates every step of PBT calibration and cal-checks. No more gas cylinders and regulators to connect and disconnect, altitude adjustments to worry about, adapters to lose, or instructions to try and remember. EASYCAL simplifies everything.

Just cradle your PBT, power on, and let EASYCAL do the rest.



Unlock the Power of Alcohol Testing

EASYCAL® G2

Automatic Calibration Station



In the department, lab or on the road, cal-checks and calibrations are accurate, effortless and worry-free. EASYCAL G2 lowers your total cost of ownership through reduced gas usage and time savings. EASYCAL G2 takes the fear out of calibration and cal-checks by reducing human error through automation and security, which prevents users from performing the wrong operation and locking down settings. Like your Lifeloc PBT, EASYCAL G2 is engineered with Lifeloc accuracy and reliability.

Fast and Simple to Use

- One-touch calibration and calibration checks
- Large color touchscreen for easy navigation
- Prints to your Lifeloc Printer
- Lab, office and mobile operation
- Reduces gas usage
- Significantly faster calibrations than the competition
- Displays date, time, and power status
- Calibration and cal-check progress bar
- Allows for up to 100 individual operators

Compliance Management Features

- Utilizes ID enabled tanks that automatically read and store tank value, expiration date and lot code
- Cylinder Expiry Lockout prevents the use of expired gas
- Gas Standard Override averts mismatch of gas standard with alcohol tester
- Low Gas Alert warns of low gas volume and shows percent tank remaining
- Calibration Warning helps prevent an inadvertent calibration after a positive test
- Auto Altitude Correction
- Security allows you to assign, enable or disable users and passwords
- Sequence Software ensures all calibrations finish with an automatic calibration check
- PBT Serial Numbers are read and stored with each cal event
- Print Log stores all cal/cal checks across unlimited breath alcohol testers

Display	Full Color Digital LCD Resistive Touchscreen
Cylinder Size	Accommodates 34L, 60L, 105L and 116L gas cylinders
Available Gas Standards	0.040, 0.080, 0.100**
PBT Seat Sensor	Ensures Proper Device Seating
Cylinder Pressure Sensor	Automatically checks tank volume
Barometric Pressure Sensor	Automatically Corrects Altitude
Recovery Time	Immediate
Calibration Time	< 2 minutes
Calibration Check Time	< 30 seconds
Operating Temperature Range	50° - 113° F (10° - 45° C)
User Selectable Power Options	9VDC A Regulated 6 C Alkaline Auto Sleep Mode
Power Save Feature	Auto Shutoff
Dimensions	Approx. 10.5" L x 9.25" W x 5.3" H (266 x 235 x 135 mm)
Weight	3 Pounds (48 ounces, 1360 grams)
Printer Communication Standard	Bluetooth
Software Updates	Field updatability via USB
Memory	Approx. 10,000 records before overwriting
Unit of Measure	BAC Standard International UOM Available
Language	English Standard Additional Languages Available.
Date/Time	User Selectable International Date and Time Formats
Certifications	CE
Housing	Ruggedized ABS Plastic
Warranty	2 year Limited Parts and Labor

**Other Common Standards Available Upon Request

All of Lifeloc's Breath Alcohol Testers are DOT/NHTSA approved.