

Lifeloc

Professional Breath Alcohol Tester

Unlock the power of the FC20BT™

Bluetooth®. Lifeloc's premium portable breath alcohol tester now comes with wireless capability allowing for trouble-free connection to other Bluetooth devices. Easy, fast and reliable just got better.



Unlock the Power
of Alcohol Testing

www.lifeloc.com

Product Innovation

- Factory Synched Kits – Test Right Out of the Box
- Encrypted Wireless Communication
- Wireless Printing and Data Entry
- Customizable Menu Driven Software
- Blue LED Communication Indicator On All Devices
- Security Features Include:
 - Password protection
 - Calibration and reminder lockouts
 - Breath pressure sensor prevents test until subject begins blowing
- AlcoMark® Software Compatible
- Data Management Solutions with Keyboard
- 4000 Test Memory
- Available Printer with Audible “Beeps” and Charge Indicator

Five Star Customer Care

- Live, Onsite Technical Support
- Repairs Guaranteed in Five Days
- Comprehensive Service Packages
- Training Solutions & Supplies
- Proudly Manufactured in the USA

Precision Instrument

- Platinum Fuel Cell Sensor
 - Superior accuracy and life
 - Alcohol specific
- Double Pump Sampling System Allows for Unsurpassed Passive Testing
 - Perfect for open container or crowd testing
- Rapid & Repeatable Testing
 - Immediate response and recovery on negative
 - <10 seconds response on positive, <30 seconds recovery
- Best In Class Operating Temperature Range
 - 0-55° C or 32-130° F
- Barometric Pressure Sensor (optional)

Ease of Use

- User Selectable Test Modes
 - Auto, Manual and Passive options
- Dual Trigger Modes
 - End of breath or precise volume
- Large Backlit LCD Display
 - 64 character display
 - No codes to look up, full text prompts
- Sturdy & Rugged Design
- Long Battery Life



The FC20BT Kit includes:

FC20BT breath alcohol tester, wireless thermal printer, Thermalast thermal paper, printer charger, 4 AA batteries, 10 EasyTab™ mouthpieces, protective grip, wrist strap, user manual, training CD, 1 year warranty and rugged carrying case.



The FC20BT DMS Kit Includes:

FC20BT breath alcohol tester, foldable compact wireless keyboard, wireless thermal printer, Thermalast thermal paper, printer charger, 4 AA batteries, 10 EasyTab™ mouthpieces, protective grip, wrist strap, user manual, training CD, 1 year warranty and rugged carrying case.

All of Lifeloc's Breath Alcohol Testers are DOT/NHTSA approved.