



## Law Enforcement Buyer's Guide

FC10: Automatic and Manual Test modes, last test recall

FC10*Plus*: Automatic, Manual, and Passive Test modes, last test recall

FC20: Automatic, Manual, and Passive Test modes, 500 event memory, print capability, and more.

FC20Kit: Combines FC20 with Thermal or Impact Printer in a convenient carrying case

Primary Use / Application:	Common Offenses:	Recommendation	Comments
<p><b>Municipal Police Forces State Police / Highway Patrol/ Sheriff's Dept's</b></p> <p>Accurate, fast screening in support of roadside Field Sobriety Testing</p> <p>DUI enforcement where a numerical BAC value is required.</p> <hr/> <p>If printing or downloading of test results, and/or calibration data, is required.</p>	<p>DUI, DWI, OWI</p>	<p><b>Lifeloc model FC10</b></p> <hr/> <p><b>Model FC20</b> with either: * <b>DataTrak</b> software for printing from PC * <b>Printer kit</b> for portable print capability</p>	<p>Fast, easy-to-use operation</p> <p>Automatic and Manual test modes</p> <p>Last test recall</p> <p>Exceptional battery life</p> <hr/> <p>The FC20 has a 500 event internal memory and clock to date/time stamp all activities.</p>
<p><b>Checkpoints/Roadblocks</b></p>	<p>DUI, DWI, OWI</p>	<p><b>FC10Plus</b></p>	<p>Additional Passive testing mode provides capability for repetitive screening test every 30 seconds virtually without limit. If positive result is detected, unit can be switched to AutoTest (with mouthpiece) to enable officer to obtain BAC level.</p>
<p><b>Police, Sheriff's, and School Resource Officers</b></p> <p>For underage drinking and zero tolerance situations where any use or possession of alcohol is a violation.</p>	<p>Screening: Juvenile parties Minor in Possession of Alcohol Open Container, Underage Consumption Possession of alcohol on school property, etc.</p>	<p><b>FC10Plus</b></p>	<p>Automatic, Manual, and Passive test modes.</p> <p>Last test recall.</p> <p>Passive testing is used to determine the presence of alcohol.</p> <p>Can be used for subject's breath or to check for alcohol in an open cup or container.</p>



<p><b>Juvenile Enforcement Officers</b></p> <p>Where printed results are needed for documentation</p>	<p>Minor in Possession of Alcohol, Open Container, Underage Consumption, Possession of alcohol on school property, etc.</p>	<p><b>FC20</b> with either:</p> <p><b>DataTrak</b> software for printing from PC</p> <p><b>Printer kit</b> for portable print capability</p>	<p>FC20 has Automatic, Manual, and Passive test modes; 500 event memory, printing capability, and numerous other features</p>
<p><b>Law Enforcement and Administrative Authorities</b></p> <p>Situations requiring screening and confirmation testing in accordance with establish protocols</p>	<p>Generally used for civil or administrative hearings that require confirmatory breath alcohol testing, including air blanks prior to each test.</p>	<p><b>FC20</b> Using:</p> <ol style="list-style-type: none"> <li><b>DataTrak™</b> software for printing from PC</li> </ol> <p><b>Printer Kit</b> for portable print capability (or)</p> <ol style="list-style-type: none"> <li><b>Sequence Software</b> for step-by-step test protocol</li> </ol>	<p>Sequence™ is a step-by-step screening and confirmation testing protocol pre-programmed into the instruments software. It guides the operator through the testing process. Can be customized for individual agencies testing policies and protocol. All test results are documented in memory and can be printed.</p>